

**NFPA 72 § 24.5.2 (2013, 2010)**

**24.5.2.3.1 Inbound** A minimum inbound signal strength of -95 dBm, or other signal strength as required by the authority having jurisdiction, shall be provided throughout the coverage area.

**24.5.2.3.2 Outbound** A minimum outbound signal strength of -95 dBm at the donor site, or other signal strength as required by the authority having jurisdiction, shall be provided throughout the coverage area.

**IFC § 510 (2015, 2012)**

**510.4.1.1 Minimum signal strength into the building** A minimum signal strength of -95 dBm shall be receivable within the building.

**510.4.1.1 Minimum signal strength out of the building** A minimum signal strength of -95 dBm shall be received by the Agency's radio system when transmitted from within the building.

**IBC § 916 (2015)**

**916.1 General** Emergency responder radio coverage shall be provided in all new buildings in accordance with Section 510 of the International Fire Code.

**What are the code-required minimum inbound / outbound signal strengths?**

-95 dBm is the code-required minimum for both inbound (received) and outbound (talk-back) signal strengths. Please refer to NFPA 72 § 24.5.2 (2013,2010), IFC § 510 (2015,2012) and IBC § 916 (2015) in the sidebar.

However, it's easy to overlook the outbound signal strength minimum requirement since signal strength readings are generally only performed in-building and not at the donor site.

If signal strength readings are not performed at the donor site, how is it possible to ensure a minimum outbound signal strength of -95 dBm? The answer is by calculating the outbound signal strength based on the inbound signal strength.

First we need to determine the *signal strength difference* between the *donor site ERP* (effective radiated power) and the *portable radio's ERP*, typically 34 dBm [Fig. 1]. Then we need to subtract the *signal strength difference* from our *in-building signal strength* reading to determine the *outbound signal strength* [Fig. 2]:

$$\left( \begin{matrix} [W \leftrightarrow \text{dBm}] \\ \text{DONOR ERP} \end{matrix} \right) - \left( \begin{matrix} [34 \text{ dBm}] \\ \text{RADIO ERP} \end{matrix} \right) = \text{SIGNAL STRENGTH DIFFERENCE}$$

Fig1.

$$\left( \begin{matrix} \text{INBOUND} \\ \text{SIGNAL} \\ \text{STRENGTH} \end{matrix} \right) - \left( \begin{matrix} \text{SIGNAL} \\ \text{STRENGTH} \\ \text{DIFFERENCE} \end{matrix} \right) = \text{OUTBOUND SIGNAL STRENGTH}$$

Fig2.

In the example below, -85 dBm is the inbound signal strength and 13 dB is the signal strength difference (47dBm - 34 dBm = 13 dB). We can calculate the outbound signal strength as -98 dBm (-85 dBm - 13 dB = -98 dBm). Although the minimum inbound signal strength is met, the site survey will fail since the outbound signal strength is below the required -95 dBm minimum [Fig. 3].

